



Fig. 40—Layout of Overdrive Parts

1. Transmission Mainshaft
2. Energizing Spring
3. Second Speed Gear
4. Thrust Washer
5. Thrust Washer Drive Pin
6. Mainshaft Bearing
7. Snap Ring
8. Snap Ring
9. Oil Baffle
10. Gasket
11. Adapter
12. Sun Gear Control Plate
13. Blocker Ring
14. Control Plate Retainer
15. Control Plate Retainer Snap Ring
16. Shift Rail Collar Snap Ring

17. Shift Rail Collar
18. Sun Gear
19. Pinion Cage Assembly
20. Cam Retaining "U" Clip (Large)
21. Cam Rollers
22. Cam Roller Cage
23. Roller Cage Retracting Spring
24. Free-Wheeling Cam
25. Cam Retaining "U" Clip (Small)
26. Shift Rail Retractor Spring
27. Shift Rail Assembly
28. Sun Gear Solenoid
29. Sun Gear Pawl
30. Sun Gear Pawl Rod Oil Seal
31. Control Cable Bracket
32. Ring Gear

33. Output Shaft
34. Ring Gear Snap Ring
35. Output Shaft Bearing
36. Woodruff Key
37. Speedometer Drive Gear
38. Drive Gear Snap Ring
39. Bearing Snap Ring
40. Governor Switch
41. Plug
42. Control Shaft Locating Pin
43. Oil Seal
44. Gasket
45. Overdrive Housing
46. Shift Rail Control Shaft and Lever
48. Speedometer Driven Gear and Filing
49. Lock Plate